



HOBO® U24-001 Data Logger

Fresh Water Conductivity Data Logger

This high-accuracy conductivity data logger is a cost-effective way to collect water quality data. The HOBO U24 measures and records both conductivity and temperatures in streams, lakes, and other freshwater sources. This logger is recommended for monitoring aquifers for saltwater intrusion and road and agricultural runoff. This product's open access to its sensor simplifies cleaning and maintenance. The HOBO U24's non-contact sensor minimizes measurement errors related to drift. In addition, the logger features software-based drift compensation.



The HOBO U24 Conductivity data logger features a non-contact sensor with a Titanium Pentoxide coating. This coating prevents the sensor from coming in contact with the water, which in turn prevents tarnishing or corrosion associated with traditional electrode sensors. This sensor coating is also inert, enabling fouling to be easily wiped off the sensor.

Supported Measurements:

Conductivity/Salinity and Temperature

Key Advantages:

- Non-contact sensor provides long life and less measurement drift
- Provides easy access to sensor for cleaning and shedding air bubbles
- HOBOware Pro software enables start/end-point calibration to compensate for any fouling and provides easy conversion to specific conductance and salinity
- USB optical interface provides high-speed, reliable data offload in wet environments
- Compatible with the HOBO Waterproof Shuttle for easy and reliable data retrieval and transport

The HOBO U24 Conductivity data logger features a non-contact sensor with a Titanium Pentoxide coating. This coating prevents the sensor from coming in contact with the water, which in turn prevents tarnishing or corrosion associated with traditional electrode sensors. This sensor coating is also inert, enabling fouling to be easily wiped off the sensor.

HOBO U24-001 Data Logger Specifications

Memory: 18,500 temperature and conductivity measurements when using one conductivity range; 11,500 sets of measurements when using both conductivity ranges (64 KB total memory)

Sample rate: 1 second to 18 hrs, fixed or multiple-rate sampling with up to 8 user-defined sampling intervals

Battery life: 3 years (@ 1 min logging)

Maximum depth: 70 m (225')

Operating range: -2 to 36°C (28° to 97°F) - non freezing

Weight: 193 gm (6.82 ounces), buoyancy in freshwater: -59.8 gm (-2.11 ounces)

Size: 3.18 cm diameter x 16.5 cm, with 6.3 mm mounting hole (1.25" diameter x 6.5", " hole)

Calibrated range: *Conductivity:* Low Range: 0 to 1,000 µS/cm; Full Range: 0 to 10,000 µS/cm - *Temperature:* 5 to 35C (41 to 95F)

Accuracy: *Conductivity:* 3% of reading, or 5 µS/cm, whichever is greater / *Temperature:* 0.1C (0.2F)

Resolution: *Conductivity:* 1 uS/cm - *Temperature:* 0.01°C (0.02°F)

Response time: 1 second to 90% of change

Environmental Rating: IP68

Contact Us

Sales (8am to 5pm ET, Monday through Friday)

▶ Email sales@onsetcomp.com

▶ Call 1-508-759-9500

▶ In U.S. toll free 1-800-564-4377

▶ Fax 1-508-759-9100

Technical Support (8am to 8pm ET, Monday through Friday)

▶ Contact Product Support www.onsetcomp.com/support/contact

▶ Call 1-508-759-9500

▶ In U.S. toll free 1-877-564-4377

Onset Computer Corporation

470 MacArthur Boulevard

Bourne, MA 02532